

Механічна клавіатура MK130R




Технічні характеристики:

1. Форм-фактор: 60%;
2. Габарити: 292,5*100,2*38мм;
3. Вага: 550±20г;
4. Кількість клавіш: 61;
5. Колір корпусу: чорний;
6. Колір кейкапів: білий, синій, помаранчевий;
7. RGB-підсвічування;
8. Два шумопоглинаючі шари піни EVA;
9. Повна підтримка функції Anti-Ghosting (NKRO);
10. Знімні перемикачі;
11. Тип перемикачів: outemu red;
12. Ресурс перемикачів: 50 млн циклів;
13. Сила натискання: 45 г +/- 10%;
14. Хід перемикача до спрацювання: 2.0 +/- 0.6 мм;
15. Загальний хід перемикача: 4.0 +/- 0.6 мм;
16. З'ємний type-c кабель довжиною 1.8м;
17. Сумісність з операційними системами: Win 7 / Win 8 / Win 10 / Win 11;
18. Комплектація: знімний кабель USB-A / USB-C, два запасні перемикачі outemu red switch, пуллер для кейкапів, пуллер для перемикачів, додатковий набір кейкапів;

Функціональні комбінації та їх значення:

Комбінації клавіш	Функції
FN + 1	F1
FN + 2	F2
FN + 3	F3
FN + 4	F4
FN + 5	F5
FN + 6	F6
FN + 7	F7
FN + 8	F8
FN + 9	F9

FN + 0	F10
FN + -	F11
FN + =	F12
FN + R	Медіа плеєр
FN + X	Зменшити гучність
FN + Z	Збільшити гучність
FN + C	Вимкнути звук
FN + F	Зупинити відтворення
FN + A	Попередній трек
FN + D	Відтворення / Пауза
FN + S	Наступний трек
FN + E	Електронна пошта
FN + Q	Головна сторінка
FN + W	Мій комп'ютер
FN + T	Калькулятор
FN + I	Scroll lock
FN + J	Insert
FN + U	Print Screen
FN + O	Pause
FN + K	Home
FN + L	PgUp
FN + M	Delete
FN + Win	Блокування / Розблокування клавіші Windows
FN + ,	End
FN + .	PgDn
FN + Right Alt	←
FN + Right Ctrl	→
FN + /?	↑
FN + 	↓
FN + ESC	Перезавантажити (утримання клавіш на протязі трьох секунд)
FN + TAP	Змінити режим підсвічування
FN + ENTER	Змінити колір підсвічування
FN + 	Увімкнути / Вимкнути підсвічування
FN +]}	Збільшити яскравість підсвічування
FN + [{	Зменшити яскравість підсвічування
FN + ;:	Зменшити швидкість режиму підсвічування
FN + ' "	Збільшити швидкість режиму підсвічування
FN + Right Shift	Перейти до функцій клавіш зі стрілками (утримуйте комбінацію клавіш 3 секунди), після повторного утримання клавіш протягом трьох секунд, клавіші повертаються до звичайного режиму роботи

Mechanical keyboard MK130R




Technical characteristics:

1. Form factor: 60%;
2. Dimensions: 292.5*100.2*38mm;
3. Weight: 550±20 g;
4. Number of keys: 61;
5. Body color: black;
6. Caption colors: white, blue, orange;
7. RGB backlight;
8. Two noise-absorbing layers of EVA foam;
9. Full support for the Anti-Ghosting (NKRO) function;
10. Removable switches;
11. Type of switches: outemu red;
12. Resource of switches: 50 million cycles;
13. Pressing force: 45 g +/- 10%;
14. Switch travel before actuation: 2.0 +/- 0.6 mm;
15. Total travel of the switch: 4.0 +/- 0.6 mm;
16. Removable type-c cable 1.8m long;
17. Compatible with operating systems: Win 7 / Win 8 / Win 10 / Win 11;
18. Package contents: removable USB-A / USB-C cable, two spare outemu red switches, capture puller, switch puller, additional keycaps set;

Functional combinations and their meanings:

Keyboard shortcuts	Functions
FN + 1	F1
FN + 2	F2
FN + 3	F3
FN + 4	F4
FN + 5	F5
FN + 6	F6
FN + 7	F7
FN + 8	F8
FN + 9	F9

FN + 0	F10
FN + -	F11
FN + =	F12
FN + R	Media player
FN + X	Turn down the volume
FN + Z	Increase the volume
FN + C	Turn off the sound
FN + F	Stop playback
FN + A	Previous track
FN + D	Play / Pause
FN + S	Next track
FN + E	Email
FN + Q	Home page
FN + W	My computer
FN + T	Calculator
FN + I	Scroll lock
FN + J	Insert
FN + U	Print Screen
FN + O	Pause
FN + K	Home
FN + L	PgUp
FN + M	Delete
FN + Win	Lock / Unlock the Windows key
FN+ ,	End
FN+ .	PgDn
FN + Right Alt	←
FN + Right Ctrl	→
FN + /?	↑
FN + 	↓
FN + ESC	Reboot (hold down the keys for three seconds)
FN + TAP	Change the backlight mode
FN + ENTER	Change the backlight color
FN + 	Turn on / off the backlight
FN+]}	Increase the brightness of the backlight
FN + [{	Reduce the brightness of the backlight
FN + ;:	Reduce the speed of the backlight mode
FN+'''	Increase the speed of the backlight mode
FN + Right Shift	Switch to the arrow keys functions (hold down the key combination for 3 seconds), after holding down the keys again for three seconds, the keys return to the normal mode of operation