Gelius

Model:
GP-PK005

SMART
KIDS WATCH

Посібник користувача

Елементи в упаковці і специфікації

Комплектація:
- Годинник
- Магнітний зарядний пристрій USB
- Сенсорний стилус для екрана годинника
- Посібник користувача з гарантійним талоном

УВАГА:
Спорт годинник не слід використовувати для будь-яких медичних цілей!

БАТАРЕЯ ЗАМУКА:
Замки при радіосигналі вогнем
Замки при радіосигналі обмеженим радіосигнал-випромінювачем, як встановлений для максимізованого покриття.
Замки при радіосигналі розташовуються тільки або працювати сплошь з будь-якою послуги активної або передавання.

Специфікації:
Назва: GP-PK005
Напруга живлення: 5В
Робоча температура: 0°C-40°C
Підтримка мережі: 2G GSM, 3G WCDMA і 4G TD/FDD-LTE

Інструкція з експлуатації

1. Приобрайте SIM-карту у мобільного оператора

1) Вибрать SIM-карту згідно з рекомендаціями вашого оператора. Переконайтеся, що для вашого NANO, а не оператора. Зазвичай SIM-карти.
Будь ласка, звернутися до служби підтримки клієнтів, якщо у вас виникли запитання.
2) Для 4G-мережі вибрати підтримується мережу 4G з потоковим передаванням даних та відеоми часом.

Інструкція з експлуатації

2. Як встановити SIM-карту?

1) Вимкніть пояс для SIM-карти, карту чіпсетом лицьовою стороною догори пальцем у пазах.

Інструкція з експлуатації

3. Завантажте додаток

1) Відкрийте на вашому смартфоні додаток для сумісними QR коди і відскануйте QR код, наведе, завантажте і встановіть його.

2) Або знайдіть новий додаток SeTracker у магазині Apple або Google Play для завантаження та встановлення.

Інструкція з експлуатації

4. Реєстрація

1) Після завершення установки розпочніть реєстрацію особистого облікового запису.

- **Код регістру** (двозначний номер або код регістру, а не номер PR)
- **Обліковий запис** (ваш номер телефону або ім'я облікового запису)
- **Пароль** (встановіть пароль із цифр або літер (не забудьте його)
- **Виберіть мову додатку**: виберіть свою місцевомовщину (Україна та Україна, Азія та Океанія, Північна Америка та Південна Америка)

Інструкція з експлуатації

5. Увійдіть

Після реєстрації спробуйте увійти

- **Введіть свій обліковий запис і пароль**
- **Виберіть мову програми:**
  Виберіть свою місцевомовщину (Україна, Україна, Азія та Океанія, Північна Америка та Південна Америка)

Інструкція з експлуатації

6. Додайте пристрій

Перейдіть до розділу «Я», щоб знайти стиль пристрою, і відскануйте реєстраційний код, щоб додати годинник.

Інструкція з експлуатації

7. Підтвердіть успішне зчитування з годинником

Будь ласка, перейдіть до розділу «Пошук годинника», щоб перевірити правильність підключення годинника, що означає успішне підключення годинника та пристрою.

Інструкція з експлуатації

8. Налаштування

1) Натисніть і виберіть налаштування, натисніть на телефону книгу або натисніть на збережену потрібні номери. Те ж саме стосується в Білих номерів.

- Встановлення SOS номер (Ім'я / Батько / Брат)
- Тільки номери, збережені в телефонній книзі або контакти, якщо прийде дзвонити на годинник, запропонуйте дзвонити другим.
- Як показано: вберіть номери з додатку під годинник, якщо вимкнули у номеру.
- Не забудьте натиснути кнопку збереження

FAQ Центр

Про SIM-карту:

1 Має мережу GPRS
2 Має потокову передачу даних 4G
3 Може відправляти дзвінковерхню обличчя

Інструкція з експлуатації

9. Виклик

1) Щоб подзвонити по телефону з годинника:
Ці дзвонители тільки призначені в мережу лікарю або приватну, а також для тих, хто вказаний у вашому білому списку. Крім того, ви зберігаєте дзвінки в додатку (можна встановити 10 номерів), написати номер, який потребує зателефонувати.
2) Натисніть на кнопку дзвінка і протягом кілька секунд, як показано на малюнку нижче. Якщо пізніший, а також від номера, що не зареєстрований, Якщо ви натиснули SOS щоби ви дзвоните, Ваш годинник подзвонить на 3 номери.
Просто дзвоните номер, який ви обрали в додатку (у Білих номерів, якщо ви натиснули у, щоб відповісти, натисніть кнопку 1 щоб скинути.

FAQ Центр

Про SIM-карту:

1 Має мережу GPRS
2 Має потокову передачу даних 4G
3 Може відправляти дзвінковерхню обличчя

Інструкція з експлуатації

10. Розпізнавання

1) Увімкніть годинник і переконайтеся, що мережа працює.
2) Відкрийте карту у додатку, натисніть під розпізнаванням, після чого ваш годинник почне пошук вашого дзвінка в реальному часі.

Примітки: Якщо годинник знаходиться в приміщенні, все зовнішні сигнали GPS, Wi-Fi та базової станції будуть слабкими, і ваш годинник може перейти на резервні. Зазвичай стандарт, а також від навколишнього середовища. Якщо ви перебуваєте за межами, ви автоматично отримаєте точне місце розташування. Якщо ви знаходитесь в приміщенні, для вас варто стає настійливим під час перевищення годинника для є нормальним, як не можете розпізнати його за певним часу, не будь ласкавий в послуговуючи обслуговування.

FAQ Центр

Питання та відповіді

1. Якщо на годинник SIM-карта, а вона все одно не отримує сигналу
Спробуйте вийняти SIM-карту, перевірте, чи вона підходить, а також перевірте, не карта підходить мережу 4G.
2) Відкрийте карту у додатку, натисніть під розпізнаванням, після чого ваш годинник почне пошук вашого дзвінка в реальному часі.

2. Так, що збережемо номера повідомлень, що прийшли на мою телефонну книгу?
1 Будь ласка, перевірте, чи слід часто не включене на, чи вона дозволяється на годинник.
2 Якщо ні, будь ласка, перейдіть до розділу «Я», перейдіть до годинника (через використання додатку годинник при їзді до дитинами).

FAQ Центр

4. Чо, не можна отримати автоматично
Коли ви знаєте, що ваш годинник, годинник автоматично скинуть час, що ваш годинник, що ваш годинник, що ваш годинник.
2) Спробуйте відкрити додаток, а потім натисніть на кнопку «Я», а потім натисніть на кнопку «Пошук годинника».

5. Функція позиціонування не працює
1) Відкрийте на вашому годиннику дзвінок.
2) Як тільки годинник перейде в РЕЖИМ СНУ, ми перейдіть в РЕЖИМ ОЧІКУВАННЯ, і ви не зможете отримати дзвінок, а також не зможете ПЕРЕЙТИ, а для цих як потрібно скинути позиціонування годинник годинник, щоб розбудити.

6. Не передача, не зекотнутрати
Акумулятор вкрадеть в дивним (ймовірність), виняткуйте чи(тут кроки) Ваш годинник? Або кажуть, щоб перевірити, чи не пошукачевий (зустрівшаяся)

FAQ Центр

Натисніть клавішу POWER протягом 30 секунд, а потім перезавантаж, вона покаже перезавантаж на годинника через 1 хвилину, а дай час до 30 секунд, щоб перезавантажити.
2) Якщо годинник не зарядився, ймовірно, що акумулятор, через тривалий час, перейдіть на ВИМК.

FAQ Центр

1 Чому годинник не отримує дзвінки?
1) Перевірте, чи є у вас дзвінки, а також, чи не вимкнено, а також, чи не вимкнено.
2) Перевірте, чи не вимкнено, а також, чи не вимкнено.

2 Чо, що, якщо я не можу зробити дзвінок?
1) Будь ласка, перевірте, чи є у вас на годинник.
2) Перевірте, чи є у вас на годинник, а також, чи не вимкнено.

3 Чому, якщо я не можу зробити дзвінок?
1) Будь ласка, перевірте, чи є у вас на годинник.
2) Перевірте, чи є у вас на годинник, а також, чи не вимкнено.

4. Чо, що, якщо я не можу зробити дзвінок?
1) Будь ласка, перевірте, чи є у вас на годинник.
2) Перевірте, чи є у вас на годинник, а також, чи не вимкнено.

5. Функція позиціонування не працює
1) Відкрийте на вашому годиннику дзвінок.
2) Як тільки годинник перейде в РЕЖИМ СНУ, ми перейдіть в РЕЖИМ ОЧІКУВАННЯ, і ви не зможете отримати дзвінок, а також не зможете ПЕРЕЙТИ, а для цих як потрібно скинути позиціонування годинник, щоб розбудити.

6. Не передача, не зекотнутрати
Акумулятор вкрадеть в дивним (ймовірність), виняткуйте чи(тут кроки) Ваш годинник? Або кажуть, щоб перевірити, чи не пошукачевий (зустрівшаяся)

FAQ Центр

10. Як зняти через блокування PIN-коду після встановлення SIM-карти
Будь ласка, встановіть оператора для видалення. Наступними кроками: Перейдіть до «Налаштування» > «Мобільні дані» > «Мобільні дані» > «Оператор SIM-карти», натисніть на наступну мову.


Налаштування
Авіарежим
Wi-Fi
Bluetooth
Мобільні дані
Сповіщення
Звуки
Екран
Дисплей
Обої
Touch ID і пароль
Батарея
Конфіденційність
Apple ID
Назад
Мобільні дані
Мобільні дані
Мобільні дані
Мобільні дані
Оператор SIM-карти
Мобільні дані
Мобільні дані
Мобільні дані
Мобільні дані

Gellius

Model: GP-PN008

SMART KIDS WATCH

User manual

Items in the package and specifications

Complete set:
1 Watch
1 Magnetic USB charger
1 User manual (English version only)
1 User manual with warranty card

WARNING:
This smartwatch should not be used for any medical purposes.

IMPORTANT NOTE:
Statement of radiation exposure
This equipment complies with radiation exposure limits set forth for an uncontrolled environment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Specifications:
Model number: GP-PN008
Charging voltage: 5V
Working temperature: 0°C-40°C
Supported networks: 2G GSM, 3G WCDM and 4G TDD/FDD-LTE

Operating Instructions

1. Purchase a SIM card from a local operator

1) Choose a SIM card according to your operator's requirements (Please make sure it is a NANO Card, not a virtual network operator)

Please contact customer service if you have any questions.
2) SIM card must support 4G network with data streaming and airtime.

Operating Instructions

2. How to install a SIM card?

1) Pull out the SIM card tray, place the SIM card with the chipset face up in the tray

2) Reboot the watch after successfully inserting the card, then wait for the signal and start working with the next step.

▲ Insert the SIM card, as shown in the figure

Operating Instructions

3. Download the app

1) Open the QR code reader app on your smartphone and scan the QR code below, download and install it.

Use your own QR code reader app OR use on the left

2) Or search for the app name 'SeTracker' in the store Apple or Google Play to download and install.

Operating Instructions

4. Registration

1) After the installation is complete, start registering a personal account

- **Registry Code:** Air identification number or registry code, not an IMEI number
- **Account:** Your phone number
- **Username:** child's name
- **Password:** Set a six-digit password (don't forget it)
- **Select an app language:** Choose your language (Europe & Africa, Asia & Oceania, North America & South America)

Operating Instructions

5. Sign in

After registration, try to log in.

- **Enter your account and password**
- **Select the program language:** Select your location (Europe, Africa, Asia and Oceania, North America and South America)

Operating Instructions

6. Add a device

Go to the "Me" section to find a list of devices and scan the registration code to add the watch.

Operating Instructions

7. Confirm successful pairing with the watch

Please go to the "Find a Watch" section to ring the watch and confirm that the watch receives successful connection of the watch and the application.

Operating Instructions

8. Settings

1) Log in and find settings, click on phone book or contacts and save the numbers you want. The same applies to other functions.

- Set 500 number (Mother / Father / Brother)
- Dirsty numbers saved in the phone book or contacts have the right to call the watch, suggest to add friends.
- You have to save the numbers in the app, then the watch can call those numbers.
- Don't forget to click the save button.

Operating Instructions

9. Challenge

A) To make a phone call from the watch:
1) Use your finger to swipe left or right on the screen, find the phonebook function, click on the phone icon, the phone number you saved in the app (10 numbers can be set), click the number you want to call.
2) Keep pressing button 1 for a few seconds as shown in the figure below. If the watch is in sleep mode, one doesn't answer it, will call the three SOS numbers one after the other.

B) To call from a phone:
Just add the number you save in the app, when the watch receives a call, press button 2 to answer, press button 1 to cancel.

Operating Instructions

10. Location

1) Turn on the clock and make sure the network is working.
2) Open the map in the app, tap the location, then it will show your child's real-time position.

Notes: If the watch is indoors, it usually positions itself via LBS, and the positioning accuracy depends on the network signal strength and density and the base station and the environment. If you are outside, it will automatically switch to GPS, the deviation range will also narrow, but it may be affected by the environment and weather. The GPS function is only available in Europe and Asia, and it is a quality issue, will not be initiated in the after-sales service.

FAQ Center

About the SIM card:

1 Has GPRS network
2 Has data streaming
3 Can dial/play caller ID

Questions and answers

1. If you have inserted a SIM card and it still does not receive a signal
1) Check the card type and size to make sure it fits, and check if the card supports 4G network.
2) Insert the card into a mobile phone to make sure it is inserted correctly. First turn off the watch, then insert the card and restart.

2. When saving numbers, it says that the device cannot connect to the network
1) Please check whether there is a signal after inserting the card.
2) Check the network status.
3) Check if the watch is on (the watch must be on before using the app).

FAQ Center

1) Please make sure the SIM has a data plan and make sure you have paid for it.
2) Check whether the ID of the watch matches the ID on the app or not.
3) If it still doesn't work, please send you SD400, M, K to the phone number that is inserted in the watch, then the watch will automatically update the time and watch. Please send a message with the watch back cover number to your local dealer, they will resolve this issue as soon as possible.

3. When you call the watch, it reminds you that the dialed number is busy. Try another number.
1) Please check whether there is a signal after inserting the card.
2) Open the map in the app, tap the location, then it will show your child's real-time position.
3) Turn off the watch and restart it, then insert the card and restart the watch.

4. The time cannot be synchronized
1) Please make sure the SIM has a data plan and make sure you have paid for it.
2) Check whether the ID of the watch matches the ID on the app or not.
3) If it still doesn't work, please send you SD400, M, K to the phone number that is inserted in the watch, then the watch will automatically update the time and watch. Please send a message with the watch back cover number to your local dealer, they will resolve this issue as soon as possible.

5. The positioning function does not work
1) Check the network status.
2) Once the watch enters SLEEP MODE, it will enter POWER SAVING MODE, which means the data download function is OFF, at this time you can update the positioning and shake the watch to wake it up.

6. Does not charge, does not load
1) Please check the charging cable and mode, follow these steps:
1) Try another USB cable to see if the original one is damaged.

FAQ Center

1) Press the POWER key for 30 seconds and then reboot, it will show recharge mode, then connect to the charger for at least 30 minutes.
2) If the watch still doesn't work, the watch has a recovery time, after two days they are unplugged then recharge it, they should work.

7. The voice on the watch or phone
Check the volume 1 - Buttons call 1 the clock switches to mute and there is still no sound, the watch or mobile phone need to be repaired.

8. The watch can accept any call
Contact your local operator to obtain the Caller ID display feature.

9. When using the watch to call, indicates that it is impossible to connect
Check the GPRS signal, it is displayed on the screen. If not, maybe your SIM card is weak, try relocating again.

FAQ Center

10. How to remove the PIN code lock screen after installing a SIM card
Please enter the smartphone to remove: Settings → Security & privacy → Set SIM card lock disable → "SIM card lock" as shown in the picture below.

Specifications:
Chipset: Rockchip IPC (ARM32BI)
OS: LINUX
Processor: ASR5850, 852 MHz, single core ARM Cortex-R5 processor
Memory: 64 MB + 128 MB
Wi-Fi security: 2.5D-GC
LBS accuracy: ≤ 100 m and above
Wi-Fi accuracy: ≤ 20 m
Video call via Seitracker app or device
VoLTE - technology: OneLTE - Voice over LTE technology based on the IP multimedia subsystem (IMS) network, which allows voice services and deliver them in the form of a data stream via LTE.
RAM: 512 MB, ROM: 128 MB
Camera: 0.3 MP, 640 x 480 px
2G: GSM 850/900/1800/1900
3G WCDMA: B1/5/8 network
4G LTE: B1/3/5/7/8/20/38/40/41/B1/B7/B8/B20
SIM card: Nano SIM
Camera: front camera 2 MP
Sensor: accelerometer
Lithium battery: 350 mAh
Charging voltage: 5V, charging 0.5 mA, 2 hours
EN 50566:2013 EN 301 908-1 V13.1.01 EN 300 328 V2.2.2, EN 301 413 V1.2.1 EN 301 489-1 V2.2.1 EN 301 489-17 V3.2.1 EN 301 489-19 V2.1.1 EN 301 489-52 V1.1.1 EN 62368-1:2014/AC:2015 EN 62479:2010 EN 62311:2008 EN 62209-1:2016 EN 62209-2:2010 EN 62479:2010/AC:2011

15	Camera	Optional
16	Sensor	Optional
17	LBS	LBS + AGPS
18	GPS	AGPS (optional)
19	Wi-Fi	Wi-Fi (optional)
20	Bluetooth	Bluetooth (optional)
21	Power button	Full Stack Button
22	Input power	5 V DC up to 1 A
23	Charging temperature	Min: 0°C, Max: 40°C
24	Battery temperature	Min: -20°C, Max: 60°C
25	Battery	350 mAh
26	Charging voltage	5V, 0.5 A
27	Compatible OS	iOS 9.0+ and Android 4.4+
28	APP	SeTracker

Our company reserve the right to change and improve any features described in this manual without prior notice.
Our company reserves the right to constantly update the content of the products.

SPECIAL ATTENTION:
For other questions about using a smart watch, you can get detailed answers on the Internet or you can contact the contact where the device was purchased.
The product, accessories, user interface and other illustrations in this manual are schematic images and are for reference only.
Product appearance, colors, the actual product and shipping may vary slightly.

Equipment for GSM and UMTS digital cellular radio communication systems:

Frequency ranges, transmitter/receiver, MHz:
2 GSM/GSM-900: 880.0 – 915/925.1 – 960;
GSM-1800: 1710 – 1785/1805.1 – 1880;
3 UMTS-2100: 1920 – 1980/2110 – 2170;
Nominal transmitter output power, W: 2 (GSM-900);
1 (GSM-1800); 0.25 (UMTS);

Equipment for LTE (E-UTRA) digital cellular radio communication systems:

Frequency ranges, transmitter/receiver, MHz:
Band 3: 1710–1785/1805–1880;
Band 7: 2500–2570/2620–2690; 2500-2570/2620-2690;
Band 5: 824–849/869–894;
Band 8: 880.0–915/925.1–960;
Band 20: 832–862/791–821;
Maximum transmitter output power, W (dBm): 0.2 (23)

General info

To prevent damage or malfunction of the device, follow these rules:

Reservation

- Protect the device from excessive heat.
- Protect the device from falling.
- Do not place magnets near the sensors and speakers of water.
- Do not immerse the device in liquid.
- Do not use cleaning agents that contain alcohol, ammonia, benzene or other aggressive.
- If necessary, use a soft sponge slightly moistened with water or a weak solution to wipe/wipe/clean the product.
- Do not place the device in a high-temperature heat, such as exposure to sunlight, fire, etc.
- Do not disassemble, disassemble or modify the device, otherwise, batteries of the same or similar type should be used for replacement.
- Do not throw the battery into a fire, put it in a hot oven, break or cut it by mechanical means, as this may cause an explosion.

General info

Operating temperature, storage temperature and humidity:

- Store the device in places with a temperature from 0 to 40 °C at a relative humidity of up to 90%.
- Use the device in places with a temperature of 0 to 40°C (with a relative humidity of up to 90%).
- Battery life may be shortened in high or low temperature conditions.
- Installing a battery of the wrong type can lead to a violation of the protection system (especially when using lithium batteries of certain types).

- Do not leave the battery in places with very high temperatures, as this may cause an explosion or leakage of flammable liquid or gas.
- Protect the battery from very low atmospheric pressure, as this may cause an explosion or leakage of flammable liquid or gas.

SAFETY RULES!

- After connecting the charger, connect the USB cable (you can use a computer USB port instead of the charger or charging adapter), the desired input voltage should not exceed 5V AC.
- Do not subject the device to strong impacts.
- Do not place the device in dusty and dirty places.
- Do not disassemble or repair the device yourself.
- Do not place the device near magnetic fields, power cables, power generators, and other electronic products for disposal to specialized enterprises, or to collect points for subsequent recycling, or to return to the manufacturer. Be responsible for environmentally safe methods of storage, processing, disposal or burial of hazardous waste.
- Do not place the device, charger and use the device when taking a bath, shower, swimming pool, open body of water, body of bath water.
- You must refrain from using the device's physical buttons while it is in an aqueous environment.
Otherwise, it can lead to water ingress into the case and damage to the electronics of the device.
- Do not use the device completely dry before charging.
- To feel comfortable in the Celsius, Fahrenheit, wear them not too tight, but not too loose, leaving room for the skin to breathe.
- If you feel any skin irritation, stop using the watch, dry it and clean to ensure maximum comfort and prevent premature wear of watch components.
- Too tight tightening of the bracelet can cause irritation, and too loose - rubbing.

Do not forget about the hygiene of both the watch itself and the straps, as well as the skin.

Explanation!

Determining the location of the child's area function of the smart watch. The communication sensors in the children's watch are responsible for this function. The watch's communication sensor uses the cellular network to connect to the child's geolocation request as you like every minute, once every 10 minutes and every hour (affects the state of the battery, respectively).
The watch's communication sensor is a cellular network, it will need to configure them yourself, where one module can't find a signal - the other can, most often working in turn.
In the indoor mode, you can determine the location at least every 10 seconds, if there is no magnetic of mobile internet or the GPS and the location request will not be sent.

LBS – location search using the nearest GSM antenna of the mobile operator and Wi-Fi data transmission. It is divided into two parts, each of which is responsible for a lower The system is not entirely accurate and the calculations can be from 50 to 1500 m. It depends on the number of towers of your mobile operator in your area, the number of Wi-Fi routers and how accurately accuracy is place where the GPS signal does not pass, for example, through thick walls of a building, or where there is no Wi-Fi. We recommend that you do not disable this function.

- GPS is the most accurate way of determining coordinates using a direct connection to a satellite The accuracy is 5-10 m, but in bad weather and near tall buildings, the connection may deteriorate. The operation of the GPS receiver depends on the GPS satellite system, which is under the control of the world, is far away, it may be necessary to wind up GPS until the connection is established, which may take 30 seconds or more.

Wi-Fi – This method is used only for finding coordinates indoors. It often happens that the GPS signal disappears or weakens in buildings, in such cases Wi-Fi is automatically turned on. It does not show the place where the gadget is located, but only the Wi-Fi hotspot to which it is connected. The accuracy of the address depends on the strength of the signal and the more precise prescribed coordinates to the Wi-Fi access point and can be 10-40 meters or more, depending on the number of hotspots in the area. If Wi-Fi does not need to know the password, it is enough to catch the signal.
- GSM is a common mobile communication sensor that is present in all mobile phones. It is necessary so that you can call or write a message to your child.

Safety notice
1 Read the manual and follow these instructions.
2 Keep it dry and clean.
3 Use only attachments/accessories specified by the manufacturer.

CAUTION: Do not use this product in areas where it may be submerged in water.

WARNING: Avoid using this product during thunderstorms. There may be a remote risk of electric shock from lightning.
1) Compliance with the requirements for voltage, frequency and current for the power supply, indicated on the product marking, means that using any other than specified may result in malfunctions, equipment damage, or fire hazard if restrictions are not followed.
2) The product should be connected to a grounded mains socket. Service should only be performed by a qualified service technician.
3) The equipment has a detachable power cord. The socket-outlet shall be installed near the equipment and shall be easily accessible.
4) Do not replace the power cord with a power cord that is not of the same type. Improper connection of the grounding conductor can result in a risk of electric shock. Do not bend the power cord too sharply or crush it, as this will break the continuity of the ground wire.
5) Do not disassemble the device, charger and cable, or as part of its safety certification, modification or misuse could create an electric shock hazard that could result in serious injury or death.
6) Do not use the device, charger and cable if you or the manufacturer if there are any oxidation questions before connecting the equipment.
7) Protective grounding is provided by a certified AC adapter. The building installation should provide sufficient grounding for the equipment.
8) The protective connection must be installed in accordance with local national wiring rules and regulations.
9) Use only power supplies and batteries approved by the party responsible for compliance could void the user's authority to operate the equipment.

SMS commands:

Reset to factory settings: pw,123456,factory#
Restart the device: pw,123456,reset#
Reset the device: pw,123456,rest#
Assign the main phone number (administrator): pw,123456,center,phone number#
Delete the main phone number: pw,123456,center#
Delete phone number (administrator): pw,123456,admin#
Change an administrator phone number: pw,123456,admin,phone number#
Set time and date: pw,123456,time,YYMMDDHHMM#
Set time and date: pw,123456,time,YYMMDDHHMM,+time zone#(the example: pw,123456,time,1608311200,+8#)
Select language and time zone: pw,123456,lz,LZW
Turn on/off the function of SMS in the SOS command: pw,123456 (from the administrator) phone#
Assign SOS numbers - pw, 123456, sos1,phone number #; - pw, 123456, sos2, phone number #; - pw, 123456, sos3, phone number #
Delete SOS numbers: pw,123456,sos1#; - pw, 123456,sos2 #; - pw, 123456, sos3 #. Set the APN of the cellular operator pw,123456,apn,apn name,apn username,password#
Find out IMEI: pw,123456,imei#
Assign new IMEI pw,123456,imei,xxxxxxxxxxxxx#
Find out the version of the firmware: pw,123456,version#
pw,123456,gps,0,0,0,0,0,0,0,0,0,0#

Here - the server for the region (Europe and Africa Port 8000 (or 9005) List of ip servers - Europe and Africa 52.28.152.67 - Asia and Oceania 54.169.61.255 - North America 54.153.61 - South America 18.228.68. 47:9130.192
Enable / disable the function of the SOS button: pw,123456,sos,on/off#
Add a phone SOS phone number #
Delete numbers for the set with buttons 1 and 2: pw,123456,sos#
Set the SOS text: pw,123456,sos,text#
Set the transfer interval to the server pw,123456,upload,300# (300 - time in seconds)
Enable (validate) pw,123456,monitor,on#
Disable (cancel) pw,123456,monitor,off#
Call back pw,123456,mode,1#
Disable "friend", "solo friend" function pw,123456,solofriend,0#
Enable "friend", "solo friend" function pw,123456,solofriend,1#
Inquire an e-mail pw,123456,email#
Turn off the corresponding one pw,123456,email,on#
Enable receiving voice messages in hours pw,123456,voice,on#
Disable receiving voice messages in hours pw,123456,voice,off#
Bluetooth enable pw,123456,bt,1#
Bluetooth disable pw,123456,bt,0#
Wi-Fi enable pw,123456,wifi,1#
Wi-Fi off pw,123456,wifi,0#
Hand-removal sensor (hand-removal message) pw,123456,removerm,1#
Hand-removal sensor (disable removal notification) pw,123456,removerm,0#

Automatically hang up on the watch when there is an incoming call (turn on the function) pw,123456,guanji,1#
Automatically hang up on the watch when there is an incoming call (disable the function) pw,123456,guanji,0#
Turn on the cloth vibration and sound pw,123456,yinzhe,1#
Turn on sound only pw,123456,yinzhe,2#
Turn off the cloth vibration and sound pw,123456,yinzhe,0#
Turn off both sound and vibration pw,123456,yinzhe,3#
Set the incoming call ringtone from the watch to the specified number pw,123456,ring,phone number,ringtone number#
Send an SMS on behalf of the watch to the specified number pw,123456,sms,phone number,text message#
pw,123456,call,1#(SOS1)pw,123456,call,2#(SOS2)pw,123456,call,3#(SOS3)pw,123456,call,4#(SOS4)pw,123456,call,5#(SOS5)pw,123456,call,6#(SOS6) (Example, 5 hearts pw,123456,5hearts,1#)
Turn on the pedometer pw,123456,pedo,1#
Turn off the pedometer pw,123456,pedo,0#
Find watch pw,123456,find#
Power off the clock pw,123456,poweroff#

WARNING!
Do not throw away!
Leave near Curator.

This symbol means that the product must be disposed of with household waste. The buyer is responsible for delivering the product to the place where it is disposed. The collection and separate disposal of waste is aimed at protecting the environment and human health.

Gelius

Model: GP-PK005

SMART KIDS WATCH

Instrukcja obsługi

Elementy w opakowaniu i specyfikacja

Kompletny zestaw:
- Zegarek
- Magnetyczna ładowarka USB
- Instrukcja obsługi w języku polskim
- Instrukcja obsługi aplikacji karta pwarancyjna.

OSTRZEŻENIE:
Urządzenie to nie powinien być używany do zadrutych celów medycznych.

WAŻNA UWAGA:
To urządzenie jest zgodne z limitami narażenia na promieniowanie elektromagnetyczne określonymi w zaleceniach Rady (UE) 1999/519/WE. Urządzenie znajdować się w ryzh sytuacji miejscu ani dzieciac w pobliżu,ania z jakiej inny antenny lub nadajnikiem.

Dane techniczne:
Nazwa: GP-PK005
Napięcie ładowania: 5V
Temperatura pracy: 0°C~40°C
Obsługiwane sieci: 2G GPS 3G WCDH ; 4G TDD/FDD-LTE

Instrukcja obsługi

1. Koje karta SIM od lokalnego operatora

1) Wyjmij kartę SIM (operator z zasięgiem operatora. Upewnij się, że jest to karta NANO, a nie operator sieci cellularnej.
2) Wyłącz zegarek, naciśnij i przytrzymaj przycisk zasilania.
2) Karta SIM musi obsługiwać sieć 4G ze strumieniowaniem danych i czasem antenowym.

Instrukcja obsługi

2. Jak zainstalować kartę SIM?

1) Wyłączaj kartę SIM, umieść kartę SIM chipsetem do góry w tacce.
2) Uruchom ponownie zegarek po pontyzmach włożeniu karty, a następnie poczekaj na sygnał i kopiowanie pewą od nadajnikiem kroku.

Instrukcja obsługi

3. Pobierz aplikację

1) Otwórz aplikację sklepu kodów QR na smartfonie i zeskanuj poniższy kod QR, pobierz go i zainstaluj.

2) Lub wyszukaj nazwę aplikacji: SeTracker w Apple Store lub Google Play Store, aby pobrać i zainstalować.

Instrukcja obsługi

4. Rejestracja

1) Po zakończeniu instalacji naciszczij rejestracja konta osobistego.

- **Kod rejestru** - numer identyfikacyjny lub kod rejestru, a nie numer IMEI.
- **Konto** - kod logowania.
- **Hasło** - hasło logowania.
- **Hasło** - ustaw ponownie(Przed hasło nie zapomnij go)
- **Wybierz język aplikacji** - wybierz swoją lokalizację (Europa i Afryka, Azja i Oceania, Ameryka Północna i Ameryka Południowa)

Instrukcja obsługi

5. Zaloguj się

Po rejestracji wprowadź się zalogować.

- **Wyrowadź swoją konto i hasło**
- **Wybierz język programu**
- **Wybierz strefę czasową** (Europa, Afryka, Azja i Oceania, Ameryka Północna i Ameryka Południowa)

Instrukcja obsługi

6. Dodaj urządzenie

Przejdź do sekcji „Ja", aby zmienić linie urządzeń i zeskanuj kod rejestracyjny, aby dodać zegarek.

Instrukcja obsługi

7. Poinwentaryzuj pozycjne sparowania z zegarkiem

Przejdź do sekcji „Znajdź zegarek", aby sprawdzić, czy zegarek jest prawidłowo podłączony, co oznacza, że zegarek i aplikacja zostały pomyślnie połączone.



Instrukcja obsługi

8. Ustawienia

1) Zalogą się i znajdź ustawienia, kolisz książka telefoniczną lub kontakty i zapisz zadane numery. To samo dotyczy innych funkcji.



Instrukcja obsługi

9. Wyrzwania

A. Aby wyzwonić połączenie telefoniczne z zegarka:
1.Połącz zegarek w sieci lub w sieci na telefonie, znajdź obraz kosiąb
2.Wybierz numer z listy kontaktów lub wprowadź numer ręcznie (obsługa 2) Wybrać ustawić 10 numerów(listy numer, jeszcze chosz zapisanej)

2.Naciśnij przycisk Uzyskaj kilka sekund jak połączenie na pulsacyjn rozumie, Jeśli pomyślnie lub nastąpią nie odpowie, zadzwoni na trzy numery SOS jeden po drugim.
B. Aby odebrać połączenie:
Przyjmuj dzwoną numer zapisany w aplikacji, gdy zegarek odbierze połączenie, nacisnij przycisk 2 aby odebrać, naciśnij przycisk 1 aby zakończyć.

Instrukcja obsługi

10. Lokalizacja

1) Wtłacz zegar i upewnij się, że szer. działa.
2) Otwórz mapę w aplikacji, dotknij lokalizacji, a wytwarzi się pozycja Twojego dziecka w czasie rzeczywistym.

Notatki: Jeśli zegarek znajduje się w pomieszczeniu, zwykle nie będzie miał sygnału GPS i będzie korzystał z lokalizacji sieciowej, co oznacza, że zaległości i mapy zegarkowe a dokładnie, co oznacza, jeśli jedzie na zewnątrz, automatycznie przełączy się na GPS, zakres dokładności będzie znacznie większy. Jeśli zegarek nie może ustalić pozycjonowania zegarka, co jest normalne, nie możesz uznać tego za problem z jakością, nie zostanie to wskazane po ostatnego sprzedaży.

FAQ Centrum

O karce SIM:

1 Pobierz nr GPS
2 Ma strumieniowanie danych 4G
3 może wyświetlać identyfikator dzwoniącego

Instrukcja obsługi

Pytania i odpowiedzi:

1. Jaki wskytek karta SIM i nadać do odbioru sygnału
Zegarek obsługuje karty SIM, aby upewnić się, że zegar i sprawdź, czy karta obsługuje sieć 4G.
2) Sprawdź karta, aby upewnić się, że jest prawidłowo włożona. Napęna wyłącz zegarek, a następnie włóż karty i uruchom ponownie.

2. Podczas zapisywania numeru pojawia się komunikat, że urządzenie osiągnęło maksymalną liczbę.
Jest to ograniczenie aplikacji, aby zapewnić lepszą wydajność i wyświetlanie zegarka.
Aby dodać więcej numerów, usuń jeden z istniejących numerów i następnie spróbuj ponownie.

FAQ Centrum

1) Upewnij się, że karta SIM ma pakiet danych i ma do niego zapłacilo.
2) Sprawdź, czy identyfikator zegarka jest zgodny z identyfikatorem na dodawcy (ja ja).
3) Jeśli nadal nie działa, wyłącz ją. 4) Włóż kartę telefonu przypisany do zegarka, a następnie uruchom ponownie zegarek. 5) Jeśli problem nadal występuje, wykonaj ponownie ustawienia fabryczne, a następnie spróbuj ponownie uruchomić komputer.

6. Nie będzie się, nie będzie
1) Sprawdź, czy zegarek jest naładowany, wytrzymaj niedługą kroki
2) Wypadku inny kabel USB, aby sprawdzić, czy zegarek się nie jest uszkodzony.

FAQ Centrum

2) Nacisnij przycisk POWER przez 30 sekund, a następnie uruchom ponownie, jeśli trzeba zegarek pasuje będzie, w tym czasie możesz ponownie zsynchronizować.
3) Jeśli zegarek nadal nie działa, zresetuj go, aby przywrócić ustawienia fabryczne.

7. Brak głosu w zegarku lub telefonie
Sprawdź głośność i upewnij się, że nie jest wyciszona lub na maksimum i nadal nie będzie dźwięku, oznacza to, że głośnik jest uszkodzony i wymaga naprawy.

8. Zegarek może przyjąć kodu połączenia
Sprawdź, czy zegarek obsługuje aplikację, aby uzyskać funkcje wyświetlania identyfikatora dzwoniącego.

9. Gdy zegarek jest używany do dzwonienia, wskazuje, że nie można nawiązać połączenia
Sprawdź sygnał GPS jest wyłączony na ekranie. Jeśli nie, być może twoja karta SIM jest zablo, spróbuj ponownie uruchomić komputer.

FAQ Centrum

10. Jak usunąć stare lokalizacje z mapy?
Aby usunąć stare lokalizacje, kliknij ikonę „Wyczyszczenie" w prawym dolnym rogu ekranu. Usunie to wszystkie stare punkty lokalizacji.

Clear Location
Clear Location
Clear Location