

USING GUIDE

HATOR®

DARKSIDE 2 PRO

GAMING CHAIR

SWE Användarmanual
NO Brukermanual
UK User manual
AR Manual de usuario
HE מנחל המשתמש

Lietotāja rokasgrāmata
Varotoo vadovs
Käyttöohje
TR Kullanım kılavuzu
FI Ohjekirja

Instrukcja obsługi
Manual de utilizare
Používateľská príručka
BG Ръководство за употреба
CS Uživatelský manuál
SK Používateľská príručka

User manual
Benutzerhandbuch
Manual de utilizare
Manuale d'uso
IT Manual de usuario
NL Handleiding

EN

DE

FR

IT

ES

PT

RU

UK

PL

RO

BG

CS

SK

BACKREST ADJUSTMENT

Fully pull the lever up and slowly recline the backrest backwards to the desired position. When the desired backrest angle is reached, slowly release the lever

3D ARMREST ADJUSTMENT

Press and hold the button to adjust the needed height. Rotate the armrest around the axis and move it forward or backward to find a comfortable position.

MULTI-BLOCK ADJUSTMENTS

The swing mode can be adjusted according to your weight. If the a chair does not swing, turn the handle under the seat clockwise or counterclockwise, adjusting the swing stiffness to suit you. If the swing stiffness is adjusted correctly, you can swing easily in the chair.

CHANGING THE DISTANCE BETWEEN ARMREST

You can change the distance between the armrests. Loosen the M8 screw at the bottom of the armrest and move the armrest to the desired position, then tighten the screw in the selected position.

ADJUSTING THE SEAT HEIGHT AND ROLLING MODE

- ① To lower the seat height, turn the lever handle clockwise. To increase the seat height, stand up and turn the lever handle clockwise.
- ② To turn on the swing, pull the lever to the right. The chair will rock when you lean back.
- ③ To turn off the rocking and lock the seat, align the seat in a horizontal position and push the lever to the left, towards the mechanism.

IMPORTANT



Sit in the center of the seat
Lean back on the backrest



Do not sit on the front edge of the chair



Don't step on a chair



Do not sit on the chair together



If the person is reclining in a chair, leaning back, do not move the chair



If the person is reclining in a chair, leaning back, do not overturn the chair



Do not shift the centre of gravity to the backrest



Do not insert your hand into the backrest adjustment mechanism



Sit with your clothes on. Avoid getting sweat on the upholstery of the chair

LIMITED WARRANTY TERMS

The manufacturer provides a 2-year limited warranty for all mechanical parts and components of the HATOR® Darkside 2 PRO gaming chairs.

IMPORTANT! The limited warranty does not apply to commercial use of the seat. Commercial use of the seats requires agreement with the supplier.

EN SAFETY GUIDELINES

- This chair is intended solely for its intended use.
- This chair is designed for one person use.
- To prevent the chair from tipping over:
 - Do not sit on the front edge of the seat.
 - Do not stand on the chair.
 - Do not press on the backrest when it is reclined.
- Use the product on a horizontal surface.
- When using on a hard floor, be sure to place a mat under the chair to avoid damaging the floor surface.
- When placing yourself in the chair, do so carefully to avoid applying excessive pressure to the gas lift cylinder, which could result in exceeding the set maximum load capacity.
- Move the chair carefully. While operating any function of the chair, always use smooth and controlled movements to ensure the safety of the product, humans and animals, as well as the surrounding environment.
- The armrests are designed solely to support your arms while you are seated properly in the chair. They are not intended to be used for sitting or any other unintended purpose.
- When fully reclining the backrest, it is strongly advised to keep both feet on the ground to prevent tipping or falling. Avoiding sudden or excessive force to the backrest could also cause the chair to tip over.
- Long periods at the computer and an uncomfortable position can cause discomfort and harm your health. Please try to take the most comfortable position and take timely breaks. If you experience severe discomfort or pain, stop using it immediately and consult a doctor.
- To avoid damaging the chair and causing injury, be careful when moving it, please. Pay attention to the position of your hands when adjusting the movable elements and levers.
- When adjusting the chair's height by pulling the handle, avoid using excessive force.
- The chair is created for usage in standard temperature conditions.
- Do not place the chair near heat sources to avoid surface damage and fire.
- To prevent damage and drying of PU leather, cracking of elastic components, do not put the chair near the radiator, fireplace, or other high-temperature sources and keep the chair out of direct sunlight.
- It is strictly forbidden to use the chair in places where flammable items are stored or in rooms with high humidity.
- For product safety, inspect all parts and functions every month.
- If any parts are loose, missing, or damaged, contact the reseller from whom you purchased the product. Do not use the chair until the issue is resolved.
- It is forbidden to knock out and disassemble the gas lift and other parts.
- Do not disassemble or tamper with the gas lift cylinder. Unauthorized tampering may result in explosive danger and injury.
- Do not use spare parts or accessories from third-party suppliers.
- Sit with your clothes on. Avoid getting sweat on the upholstery of the chair.
- While using the chair, avoid wearing clothing with rivets, sequins, or other sharp items that could damage the product and avoid clothing or materials that could cause discolouration of the chair.
- To prevent damage to the upholstery, keep the chair away from sharp objects, avoid rubbing against walls or furniture, and keep pets away.
- We recommend to wipe the chair after assembly in a hygienic purposes, please use an alcohol-free wipes or a special furniture cleaner according to its manual. Do not use aggressive detergents.
- Maximum recommended chair static load: 120 kg.

DE SICHERHEITSRICHTLINIEN

- Dieser Stuhl ist ausschließlich für den vorgesehenen Gebrauch bestimmt. Dieser Stuhl ist für die Benutzung durch eine Person ausgelegt.
- Um ein Umkippen des Stuhls zu verhindern:
 - Setze dich nicht auf dem Stuhl.
 - Drücke nicht auf die Rückenlehne, wenn sie zurückgeklappt ist.
- Verwenden Sie das Produkt auf einer waagerechten Oberfläche. Bei Verwenden auf einem harten Boden legen Sie unbedingt eine Matte unter den Stuhl, um Schäden an der Bodenoberfläche zu vermeiden.
- Die Rückenlehne könnte ebenfalls dazu führen, dass der Stuhl umkippt. Gassitzföhrer zu vermeiden, der zur Überschreitung der maximalen Traglastföhrer föhrt.
- Bewegen Sie den Stuhl vorsichtig. Verwenden Sie bei der Bedienung jeder Funktion des Stuhls sanfte und kontrollierte Bewegungen, um die Sicherheit des Produkts, von Menschen und Tieren sowie der Umgebung zu gewährleisten.
- Die Armlehnen sind ausschließlich dafür ausgelegt, Ihre Arme zu stützen, während Sie richtig im Stuhl sitzen. Sie sind nicht dafür gedacht, darauf zu sitzen oder für andere nicht vorgesehene Zwecke verwendet zu werden. Beim vollständigen Zurückklappen der Rückenlehne wird dringend empfohlen, beide Füße auf den Boden zu stellen, um ein Kippen oder Fallen zu vermeiden. Das Anwenden von plötzlicher oder übermäßiger Kraft auf die Rückenlehne könnte ebenfalls dazu führen, dass der Stuhl umkippt.
- Lange Zeiträume am Computer und in einer unbequemen Position können Unbehagen verursachen und Ihrer Gesundheit schaden. Versuchen Sie, die bequemste Position einzunehmen und rechtzeitig Pausen zu machen. Wenn Sie starke Beschwerden oder Schmerzen haben, hören Sie sofort auf, den Stuhl zu benutzen, und konsultieren Sie einen Arzt.
- Um Schäden am Stuhl und Verletzungen zu vermeiden, seien Sie bitte vorsichtig beim Bewegen. Achten Sie auf die Position Ihrer Hände, wenn Sie die beweglichen Elemente und Hebel einstellen.
- Vermeiden Sie übermäßige Kraftanwendung, wenn Sie die Höhe des Stuhls durch Ziehen am Hebel einstellen.
- Die Stühle sind für die Verwendung unter normalen Temperaturbedingungen ausgelegt.
- Stellen Sie den Stuhl nicht in die Nähe von Wärmequellen, um Oberflächenschäden und Brandgefahr zu vermeiden.
- Um Schäden und Austrocknen des PU-Leders sowie Risse in Kunststoffteilen zu vermeiden, stellen Sie den Stuhl nicht in die Nähe von Heizkörpern, Kaminen oder anderen Wärmequellen und vermeiden Sie direkte Sonneneinstrahlung.
- Es ist strengstens verboten, den Stuhl an Orten zu verwenden, an denen brennbare Gegenstände gelagert werden oder in Räumen mit hoher Luftfeuchtigkeit.
- Zur Produktkontrolle überprüfen Sie alle Teile und Funktionen jeden Monat.
- Wenn Teile locker, fehlen oder beschädigt sind, wenden Sie sich an den Händler, von dem Sie das Produkt gekauft haben. Verwenden Sie den Stuhl nicht, bis das Problem behoben ist.
- Es ist verboten, den Gaslift und andere Teile auszuschrauben und zu demonstrieren.
- Manipulationen oder Manipulationen Sie den Gasliftzylinder nicht. Unbefugtes Manipulieren kann zu Explosionsgefahr und Verletzungen föhren.
- Verwenden Sie keine Einzuteile oder Zubehör von Drittanbietern. Polsterung des Stuhls zu bekommen.
- Sitzen Sie mit Ihrer Kleidung darauf. Vermeiden Sie, schnell auf die Polsterung des Stuhls zu bekommen.
- Vermeiden Sie beim Benutzen des Stuhls Kleidung mit Nieten, Pfannkuchen oder anderen scharfen Gegenständen, die das Produkt beschädigen können, und vermeiden Sie Kleidung oder Materialien, die eine Verfärbung des Stuhls verursachen können.
- Um Schäden an der Polsterung zu vermeiden, halten Sie den Stuhl von scharfen Gegenständen fern, vermeiden Sie Reibung an Wänden oder Möbeln und halten Sie Haustiere fern.
- Wir empfehlen, den Stuhl nach dem Zusammenbau zu hygienischen Zwecken zu reinigen. Verwenden Sie alkoholfreie Tücher oder einen speziellen Möbelschneider gemäß dessen Anleitung. Verwenden Sie keine aggressiven Reinigungsmittel.
- Maximal empfohlene statische Belastung des Stuhls: 120 kg.

*Product and parts design are for reference only

