

Посібник
користувача

SIGNIFY RGB PRO

HTA-515

Особливості

- Plug and play, починай запис ізразу після підключення.
- 16 біт, частота дискретизації 44,1/48 КГц. Якісний запис - головне завдання.
- з регулятором пісоклення мікрофона, кнопкою вимкнення звуку.
- Легке керування вхідним звуком.
- Кардіодна схема направленості допоможе записати саме те що вам треба.
- Стала сітка, корпус із цинкового сплаву. Міцний та стильний.
- Вітроахасист та антивібраційна система ефективно зменшують шум та сповільнюють звуки.
- Особливо підходить для подкастів, контент креїторів, а також для запису музики.
- RGB підсвічування прикрасить ваше робоче місце.
- Підходить для ПК, ноутбука, PS4, PS5, Xbox, мобільного телефону з інтерфейсом типу C (Потрібен адаптер OTG Type-C)
- Підтримка операційних систем: Mac OS, Windows 7/8/10/Vista/XP.

Комплектація

- Мікрофон HATOR Signify RGB
- 2-метровий USB-A to Type-C паракордовий кабель
- Поп фільтр
- Вітроахасист
- Адаптер 3/8" на 5/8"
- Стійка пантограф з захистом від вібрації
- Посібник користувача



Огляд виробу

1. Вимкнення/Увімкнення звуку
2. RGB-підсвічування
3. Регулювання чутливості мікрофону
4. Порт USB Type-C
5. Вимкнення/Увімкнення підсвічування, зміна режиму підсвічування
6. USB-A to Type-C кабель
7. Стійка пантограф



Вид зверху

Вид спереду


Вид ззаду



- 1 Торкніться зони вимкнення звуку, щоб увімкнути/вимкнути звук.
- 2 RGB кольорове підсвічування.
- 3 Підсилення мікрофона: контролює підсилення мікрофона (чутливість). Поверніть ручку вправо, щоб збільшити рівень, і вліво, щоб зменшити рівень.
- 4 TYPE-C: стандартний Type-C роз'єм для живлення/передачі даних.
- 5 Світлові ефекти: натисніть, щоб змінити підсвітку, натисніть і утримуйте, щоб увімкнути або вимкнути її.

Монтаж мікрофона на стенд

1. Розмістіть кріплення для стійки пантографа на столі.
2. Вставте пантограф у отвір кріплення і зафіксуйте його.
3. Візьміть антивібраційне кріплення та розмістіть його на пантографі.
4. Затягніть антивібраційне кріплення на пантографі.
5. Налаштуйте кут кріплення
6. Помістіть мікрофон на антивібраційне кріплення.
7. Закріпіть мікрофон на цьому кріпленні.



Підключення до ПК

Підключіть мікрофон кабелем USB Type-A безпосередньо до комп'ютера



Для підключення мікрофону до пристройів з USB Type-C, необхідний адаптер OTG (не входить у комплект)



Підключення до смартфонів та інших пристройів з USB Type-C



Адаптер OTG підключається до USB-кабелю.



Налаштування запису

Використання з Windows

1. Відкрийте панель керування звуком на вкладці "Запис"
2. Для початку роботи з мікрофоном, виберіть "HATOR Signify" та встановіть за замовчуванням
3. Тоді весь звук буде записаний на мікрофон HATOR
4. Гучність мікрофона регулюйте за допомогою регулятора мікрофона.



Використання з Mac OS

1. Відкрийте панель керування звуком
2. Виберіть мікрофон "HATOR Signify" як вихід за замовчуванням
3. Тоді весь звук буде записуватися мікрофоном HATOR



Характеристики

Модель	Signify RGB PRO
Код товару	HTA-515
Діаграма направленості	кардіодна
Розмір капсули	діаметр 16мм
Максимальний рівень звукового тиску	125dB
Діапазон частот	20Гц-16кГц
Співвідношення сигнал/шум	≥66 dB
Розрядність	16 біт
Частота дискретизації	44,1кГц/48кГц
Чутливість	-41dB ±2dB
Робоча напруга	1-10В
Опір	600Ω
Довжина кабелю	2м
Підключення	USB Type-C
Розміри	125x50мм
Приблизна вага	210 ±5г

Зберігання. Гарантії виробника.

Зберігання

Зберігайте мікрофон слід у чистому, сухому та провітрюваному приміщенні з температурою навколошного середовища від +5 до +40 °C. Чистіть контакти з короткими пальцями, гризіть вирб подалі від вогню та підальше від джерел тепла, не залишайте мікрофон у вологому місці, якщо він не користується.

Гарантія виробника

При отриманні користувачем правил експлуатації, та з урахуванням застережень, викладених у цюні посібнику, та правил експлуатації, мікрофон HATOR може гарантіювати 12 місяців з моменту придбання та без урахування часу перебування в ремонту (при отриманні правил експлуатації), Право на гарантію надається тільки з доказом придбання та відсутністю будь-яких погань, які можуть виникнути під час нормальної експлуатації. Після здійснення ремонту, мікрофон знову має право на гарантію, якщо він було відремонтовано заради відновлення функції. Гарантія не надається на мікрофон, якщо він було відремонтовано заради змін чи видалення джерел сигналу.

Порушення правил експлуатації може привести до отримання можливості експлуатації обладнання та отримання гарантії, якщо відсутні порушення чи нечесні чинки, звернутися до служби підтримки HATOR. Гарантія є недійсною по праву, наявності відповідної згадки в умовах гарантії, якщо він було відремонтовано заради змін чи видалення джерел сигналу.

Декларація: співробітник ТОВ "НВФ 'ЕЛЕТЕК ПЛД' заявляє, що мікрофон HATOR Signify RGB PRO відповідає технічним регламентам та нормам використання дієвих небезпекних законів в електротехнічному та електронному обладнанні. Повний текст декларації про відповідність доступний на веб-сайті за адресою: <https://www.eletek.com/cert.html>

Гарантійний період: 12 місяців

©2023 HATOR. Всі права захищені. Всі зареєстровані товарні знаки є власністю їх відповідних власників.

SIGNIFY RGB PRO

HTA-515

Features

- Plug and play, start recording immediately after connecting.
- 16-bit, sampling frequency 44.1/48 KHz. High-quality recording is the main task.
- With mic gain control, mute button. Easy to control sound input.
- Cardioid directional pattern will help record exactly what you need.
- Steel mesh, zinc alloy body. Strong and sturdy.
- Wind protection and anti-vibration system effectively reduce noise and sound distortion.
- Especially suitable for podcasts, content creators, as well as for recording music.
- RGB lighting to decorate your workplace.
- Suitable for PC, laptop, PS4, PS5, Xbox, cellphone with Type-C interface (Requires OTG Type-C adapter).
- Operating system: Mac OS, Windows 7/8/10/Vista/XP.

In the box

- HATOR Signify RGB Microphone
- 2m USB-A to Type-C paracord cable
- Pop filter
- Wind protection
- Adapter 3/8" to 5/8"
- Metal arm stand with shock mount
- User manual



Product overview

1. Turn off/on the sound
2. RGB lighting
3. Adjusting the sensitivity of the microphone
4. USB Type-C port
5. Turning off/on the backlight, changing the backlight mode
6. RGB-A to Type-C cable
7. Metal arm stand



- ① Touch the mute area to turn on/off the sound.
- ② RGB color illumination.
- ③ - Microphone Gain: Controls the microphone gain (sensitivity). Turn the knob to the right to increase the level and to the left to decrease the level.
- ④ TYPE-C: Standard Type-C TYPE-C power/data connector.
- ⑤ Light Effects: Tap to change the backlight, tap and hold to turn it on or off.

Installation of the microphone on the stand

1. Place the mount for the pantograph rack on the table.
2. Insert the pantograph into the mounting hole and fix it.
3. Take the anti-vibration mount and place it on the stand.
4. Tighten the anti-vibration mount on the pantograph.
5. Adjust the pantograph angle.
6. Place the microphone on the anti-vibration mount.
7. Attach the microphone.



Connecting to PC

Connect the microphone directly to the computer with a USB Type-A cable



To connect the microphone to USB Type-C devices, an OTG adapter is required (not included).



Connection to smartphones and other devices with USB Type-C



The OTG adapter should be connected to the USB-cable.



Recording settings


For Windows OS

1. Open the sound control panel on the "Recording" tab.
2. To start working with the microphone, select "HATOR Signify" and set as default.
3. Then all sound will be recorded from the HATOR microphone.
4. Adjust the microphone volume using the control on the microphone.



For Mac OS

1. Open the sound control panel.
2. Select "HATOR Signify" as the default input.
3. Then all the sound will be recorded from the HATOR microphone.



Specifications

Model	Signify RGB PRO
Product code	HTA-515
Directivity diagram	cardioid
Capsule size	diameter 16mm
Maximum sound pressure level	125dB
Frequency range	20Hz-16kHz
Signal-to-noise ratio	≥66 dB
Bitrate	16 bits
Sampling frequency	44.1kHz/48kHz
Sensitivity	-41dB/-42dB
Operating voltage	1-10V
Resistance	600Ω
Cable length	2m
Connection	USB Type-C
Dimensions	125x50mm
Approximate weight	210±5g

Storage. Manufacturer's warranty.

Storage

The speaker should be stored in a clean, dry and ventilated place with an ambient temperature between +5 and 40°C. Avoid contact with corrosive substances, keep the product away from fire and avoid direct sunlight.

Manufacturer's warranty

Provided that the user observes the rules of operation, and taking into account the warnings set forth in this user manual, the device is safe to use and does not cause harm to the environment and humans, as well as it is suitable for operation. The device has a warranty period: 12 months from the date of purchase. The warranty period begins on the day of purchase. The warranty period is granted by filling in the information of the attached warranty card. For more information about the product, as well as for any questions or suggestions, please contact us at the address below.

The terms and conditions of the manufacturer's warranty may vary in different countries. Please read the full warranty information to learn about your consumer rights and additional remedies provided under this product warranty.

Instructions for use

- Do not attempt to open or modify.
- Do not disassemble the device or attempt to service it.
- If the product is in an environment whose temperature exceeds the permissible range, turn off the device and wait until the operating temperature stabilizes within the specified range.
- Do not allow liquid to fall on the product.
- Use the product only with certified signal sources.

Violation of the operating rules may lead to the loss of the ability to operate the equipment and the loss of the warranty.

If the product doesn't work properly, contact HATOR support.

The warranty is in addition to the rights guaranteed under local consumer laws. Its conditions may differ depending on the country.

Some forms of exercising consumer rights when ensuring product warranty obligations can be performed through retail outlets (including online stores), which, in turn, are fully responsible for compliance with consumer rights protection laws.

Supplier / Importer in EU: HATOR Gaming B.V., Address: Prins Hendrikade 21-E, 1012TL, Amsterdam, The Netherlands, sales@HATOR-99

Warranty period: 12 months